

# C.R. LAURENCE CO., INC.

## CRL Post Installation Instructions

Catalog Numbers **CR15FBBS** and **CR15FBPS**

### Installation Information:

- STEP 1 - Drill and tap post for bottom set screw
- STEP 2 - Loosen upper set screw
- STEP 3 - Gently slide post into bracket
- STEP 4 - Install bottom set screw
- STEP 5 - Align post to handrail layout
- STEP 6 - Tighten both set screws

### Tools Required:

- 5/16-18 Tap; T-Handle Tap Driver; #F Drill Bit (0.257");
- Hand Drill; 5/32" Hex Key; 3/32" Hex Key

