INSTALLATION INSTRUCTIONS

CRL DB130F SERIES DEAD BOLT HANDLE FOR ALUMINUM FRAMED DOORS





Phone: (800) 421-6144 • Fax: (800) 587-7501 crlaurence.com • usalum.com • crl-arch.com

ORDER OF ASSEMBLY AND INSTALLATION

INTRODUCTION/TOOLS REQUIRED	
DOOR PREPARATION	04-06
REMOVAL FROM PACKAGING	07-08
DEAD BOLT HANDLE INSTALLATION	

The rapidly changing technology within the architectural aluminum products industry demands that C.R. Laurence/U.S. Aluminum reserve the right to revise, discontinue, or change any product line, specification, or electronic media without prior written notice.

NOTE: Dimensions in parentheses () are millimeters unless otherwise noted.



INTRODUCTION

The CRL Dead Bolt Handle System is designed to allow maximum view and a contemporary look to your aluminum framed doors. The CRL system meets the requirements of ANSI/BHMA A156.16 Grade 1.

Tools Required


Drill bits: 9/16" (14mm), 1/2" (12mm), 3/8" (9mm) Tape Measure Saw Horses Cordless Drill 3/4" Masking Tape Framing Square/Straight Edge 1/8" (2.5mm) Allen Wrench


NOTE: Modifications, other than those specified in this document, could result in failure to meet UL safety ratings and void the manufacturer's warranties.




DOOR PREPARATION REMOVE THE DOOR AND PREPARE PER TEMPLATES

- 1. Place the door horizontally on the saw horses interior side up.
- 2. Mark the center line 2-1/4" (57.1mm) from the outside edge of the door stile. (Fig. 1)
- 3. Mark the corresponding layouts on to the door stile using the vertical center lines at the specified height. (Fig. 2)
- 4. Place the door horizontally on the saw horses exterior side up and repeat steps 2 and 3.











DOOR PREPARATION - LAYOUT SELECTION






REMOVAL FROM PACKAGING

The Handle comes mounted on a Mounting Board inside the wooden crate. Please proceed with the following steps to remove the handle from the board.




1. Remove the Socket Head Cap Screws from the Interior and Exterior Brackets and put aside for the installation.






REMOVAL FROM PACKAGING

2. Loosen the two flat head socket screws on the interior handle only so they protrude approximately 1/4" from the Cylinder Housing DO NOT TO REMOVE them, push the screws down flush and remove the interior handle from the mounting board and Cylinder Housing.




3. Remove the 2 cap screws from the inside of the Cylinder Housing, and remove the housing from the board. Remove the exterior handle, rubber bushings and save it for re-use during installation to the door.






- 4. Place the door horizontally on the saw horses exterior side up.
- 5. Place the handle on the door style and insert the mounting blocks as shown.




6. Hold the mounting blocks in place and attach the handle to the door using the two 5/16-18 x 1" low head socket cap screws. (Fig. 9)






- 7. Place the door horizontally on the saw horses interior side up.
- 8. Place the Interior Cylinder Housing to the door stile and fasten with the 2 cap screws.






9. Place the handle on the door style and insert the mounting blocks as shown.




10. Hold the mounting blocks in place and attach the handle to the door using the two 5/16-18 x 1" low head socket cap screws.






11. Re-tighten the two flat head socket screws to lock the handle to the Cylinder Housing and complete the insallation.



Exterior Handle

Interior Handle



Handle

Handle

